


MICRO HARMONIC TRANSFORMER



THE INTENSITY SWITCH ADJUSTS THE MIX OF THE TRANSFORMATION. INCREASING THE FUZZ AND BRINGING OUT MORE HARMONICS.

HARMONIC SHAPE ADJUSTS A COMPLEX FILTER CHANGING THE HARMONIC CONTENT. CHOOSE BETWEEN A DEEP FULL SPECTRUM SOUND AND A SCOOPED METALLIC SOUND.

OUTPUT:
CONNECT TO
AMPLIFIER



INPUT: CONNECT TO INSTRUMENT
DISCONNECT THE INPUT TO TURN
POWER OFF.



9 VOLT ALKALINE BATTERY INCLUDED. TO REPLACE THE BATTERY, REMOVE THE FOUR SCREWS FROM THE BACK PLATE. BE SURE TO PLACE THE BATTERY VERTICALLY BESIDE THE SWITCH ON THE FOAM PAD.



THE POWER ADAPTOR JACK ACCEPTS ANY 2.1mm 9V NEGATIVE TIP POSITIVE RING DC ADAPTOR.

DEATH BY AUDIO

www.deathbyaudio.com

